



[Maxim](#) > [Design Support](#) > [Technical Documents](#) > [Application Notes](#) > [Display Drivers](#) > APP 3729  
[Maxim](#) > [Design Support](#) > [Technical Documents](#) > [Application Notes](#) > [Microcontrollers](#) > APP 3729

Keywords: MAX6951,MAX6950,MAXQ2000,Assembly code examples, SPI interface, LED Drivers, 7-segment LED

#### APPLICATION NOTE 3729

# Using the MAX6951/MAX6950 LED Display Drivers with SPI Interface to Communicate with the MAXQ2000 Microcontroller

Feb 03, 2006

*Abstract: This application note describes assembly language techniques for the MAX6951/MAX6950 LED drivers using the MAXQ2000's SPI peripheral.*

## Introduction

The [MAX6950](#) and [MAX6951](#) are five-digit and eight-digit common-cathode LED display drivers controlled through a high-speed SPI interface. These devices employ a unique multiplexing scheme to minimize the connections between the LED driver and the LED panels. The MAXQ2000 is a high-performance 16-bit, RISC microcontroller with an integrated SPI module, which provides an easy interface between an LED driver and microcontroller. This application note gives a sample code in the MAXQ® assembly language that demonstrates how to use the MAXQ2000 SPI module to experiment with MAX6951/MAX6950 functions.

## Hardware and Software Requirements

To perform the interface experiment described in this application note, you need the [MAX6951 Evaluation Kit](#) (EV kit), the [MAXQ2000 Evaluation Kit](#) (including [MAX-IDE software](#)), a +5V power supply with minimally 200mA capacity, and a PC with an available serial port.

## Hardware Setup

1. MAX6951 EV kit jumper settings  
To disconnect signals active-low CS, DIN and SCLK from the level-translator chip on the EV kit, cut the traces connecting Pins 1 and 2 of JU2, JU3 and JU4.
2. MAXQ2000 EV kit jumper and DIP switch settings  
Set switch SW3 1-8 to the **off** position.  
JU1: connect Pins 1 and 2  
JU2: connect Pins 1 and 2  
JU3: connect Pins 1 and 2  
JU4: open  
JU10: open  
JU11: on (The MAXQ2000 EV kit is powered by a JTAG interface board, which is powered by a +5V

power supply.)

3. Connect the two EV kits as shown in **Figure 1**.




Figure 1. Schematic for the connection between the MAX6951 EV Kit and the MAXQ2000 EV Kit.

## Firmware Description

The complete firmware files for this example project can be downloaded from the Maxim website, and can be compiled using Maxim's integrated development and debugging environment, MAX-IDE for the MAXQ family of microcontrollers.

Download: [Complete Firmware](#) (ZIP, 18.8k)

### main.asm file

This file is the main demo loop for this example project. It calls different routines to demo the correct data writing to the MAX6951 registers. The firmware demonstrates the following MAX6951 functions in sequence:

1. MAX6951 SPI interface initialization.
2. In hexadecimal decode mode, the writing and displaying of 0, 1, 2, ..., A, B, C, D, E, F and 8 decimals (i.e., lighting all LED segments) to both the P0 plane and P1 plane of all the digits on the MAX6951.
3. In no-decode mode, the writing and displaying of the above letters and other recognizable letters such as H, L, P, Q, Y, etc., with custom built-in fonts.
4. LED dimming loop. This loop shows how to write to the MAX6951 intensity register to test the digital brightness control.
5. Scan limit loop. This loop displays from one to eight digits with the same intensity settings.  
**Note:** monitor the process to ensure that the brightness decreases when the scan limit increases.
6. Blinking loop. This loop writes a different digit number to plane P0 and plane P1 of every digit. It also uses a fast blinking mode to demonstrate segment-blinking control that can be synchronized across multiple LED drivers.
7. Scrolling loop. This loop scrolls a text message, HELLO, from left to right and right to left.
8. Bouncing loop. This loop bounces HELLO between the two LED edges.
9. The counting loop. This last loop shows, in both hexadecimal decode mode and no-decode mode, how to design a display that counts how many milliseconds have elapsed.

### max2000ev\_6951.asm file

This file includes all the utility functions for communicating with the MAX6951 EV kit using the MAXQ2000

microcontroller. The major functions are:

1. **max6951\_init**: This function sets the MAXQ2000 in the correct SPI mode for talking to the MAX6951. It enables SPI and initializes the MAX6951 to display eight 0s on the display panel. **Listing 1** shows this function in detail.

**Listing 1. MAX6951 initialization code sample.**

```
*****
;* Function:  max6951_init
;*
;* Sets the correct SPI modes for talking to the MAX6951, enables SPI, and
;*
;* initializes the MAX6951 to display 8 0s.
;*
;* Input:      None.
;*
;* Output:     None.
;*
;* Destroys:   ACC, A[0] -- A[10], PSF
;*
*****
MAX6951_INIT:
    ; SET SPI BAUD RATE
    MOVE      A[0], #2400H                ; SYSTEM CLOCK IS 16,000,000
    HZ
    MOVE      A[1], #00F4H
    MOVE      A[2], #4240H                ; DESIRED BAUD RATE IS
    1,000,000 HZ
    MOVE      A[3], #000FH
    CALL      SPI_SETBAUDRATE

    ; SET THE APPROPRIATE MODES FOR THE 6951
    MOVE      C, #SPI_IDLE_LOW           ; IDLE = LOW
    CALL      SPI_SETCLOCKPOLARITY
    MOVE      C, #SPI_ACTIVE_EDGE       ; ACTIVE = RISING EDGE
    CALL      SPI_SETCLOCKPHASE
    MOVE      C, #SPI_LENGTH_16        ; ALWAYS TRANSFER 16 BITS
    CALL      SPI_SETCHARACTERLENGTH
    MOVE      C, #SPI_MASTER_MODE ; MAXQ2000 IS THE MASTER, MAX6951 IS THE SLAVE
    CALL      SPI_SETMODE

    ; ENABLE SPI
    MOVE      C, #1
    CALL      SPI_ENABLE

    ; SHUTDOWN MAX6951 DISPLAY FIRST
    CALL      MAX6951_SHUTDOWN

    ; SET MAX6951 IN HEXADECIMAL DECODE MODE
    MOVE      ACC, #MAX6951REG_DECODE
    SLA4
    SLA4
    OR        #0FFH                      ; HEXADECIMAL DECODE
    CALL      MAX6951_TRANSMIT

    ; SET DISPLAY INTENSITY = 16/16
    MOVE      ACC, #MAX6951REG_INTENSITY
    SLA4
    SLA4
    OR        #0FH                      ; INTENSITY = 16/16
    CALL      MAX6951_TRANSMIT

    ; SCAN LIMIT = 7
    MOVE      ACC, #MAX6951REG_SCANLIMIT
    SLA4
    SLA4
    OR        #07H                      ; SCAN LIMIT = 7
```

```

CALL    MAX6951_TRANSMIT
RET

```

2. **max6951\_transmit**: This function sends a register address and a data byte (16 bits) to the Max6951.
3. **max6951\_set\_all\_n**: These functions set both plane P0 and plane P1 of a digit register to number 'n'. All the functions have both hexadecimal decode and no decode versions.
4. **max6951\_e\_d\_s\_d**: This function enables the MAX6951 display, then a half-second delay, shutdowns the display, and then delays for 100ms.
5. **max6951\_screenshot**: These functions put HELLO at eight different positions on the 8-digit LED panel.
6. **max6951\_scroll\_R\_to\_L**: By displaying the screenshots in different sequences, this function scrolls HELLO from right to left in no-decode mode.
7. **max6951\_scroll\_L\_to\_R**: By displaying the screenshots in different sequences, this function scrolls HELLO from left to right in no-decode mode.
8. **max6951\_bouncing**: This function bounces HELLO between the two LED edges.
9. **font\_lookup**: Given a digit value in hexadecimal format, this routine looks for the value that displays the same font in no-decode mode on a standard 7-segment LED.
10. **max6951\_counting**: This function counts and displays how many milliseconds have elapsed; the resolution is 10 milliseconds. **Listing 2** shows the code in detail.

**Listing 2. MAX6951 counting code sample.**

```

;*****
;* Function:  max6951_counting
;*
;* This routine counts how many 10-milliseconds have elapsed and displays
;* the value from 0000 to 9999 on LED digits 3-0(no way to blank leading
;* digits).
;*
;* The routine displays the same value on LED digits 7-4(by using no decode
;* mode, individual leading digits can be blanked).
;*
;* Input:      None
;*
;* Output:     None
;*
;* Destroys:   ACC, A[1] - A[4], A[9]
;*
;*****
MAX6951_COUNTING:
    CALL    MAX6951_SHUTDOWN
    CALL    MAX6951_SET_ALL_0          ; SET ALL BITS OF DATA REGISTERS TO 0
    MOVE    ACC, #010FH              ; HEXDECIMAL DECODE DIGITS 3-0, NO DECODE
DIGITS 7-4
    CALL    MAX6951_TRANSMIT
    ; INITIALIZE THE COUNT TO 0
    MOVE    A[1], #0                  ; A[1] => DIGIT 0
    MOVE    A[2], #0                  ; A[2] => DIGIT 1
    MOVE    A[3], #0                  ; A[3] => DIGIT 2
    MOVE    A[4], #0                  ; A[4] => DIGIT 3

COUNT_LOOP:
INCREASE_DIGIT3:
    MOVE    ACC, A[4]                 ; PROCESS DIGIT 3
    SUB     #9
    JUMP    Z, INCREASE_DIGIT2        ; DIGIT 3 = 9, THERE IS CARRY
OVER
    MOVE    ACC, A[4]                 ; DIGIT 3 < 9, CONTINUE
    ADD     #1
    MOVE    A[4], ACC
    CALL    FONT_LOOKUP                ; LOOK UP THE VALUE FOR THIS

```

```

FONT
UNCHANGED                                ; STORE IT IN A[9], KEEP ACC
      OR      #6300H
      CALL    MAX6951_TRANSMIT
NEW VALUE                                ; NO CARRY OVER, WRITE DIGIT 3
      MOVE    ACC, A[9]
DIGIT 7                                  ; WRITE THE NO DECODE VALUE TO
      OR      #6700H
      CALL    MAX6951_TRANSMIT
      JUMP    DISPLAY_NUMBER

INCREASE_DIGIT2:
      OR      #6300H
      CALL    MAX6951_TRANSMIT           ; WRITE 0 TO DIGIT 3 REGISTER
FIRST
      MOVE    A[4], #0                   ; SET DIGIT 3 BACK TO 0
      MOVE    ACC, #677EH                ; NO DECODE VALUE FOR FONT '0'
IS "7EH"
REGISTER
      CALL    MAX6951_TRANSMIT           ; WRITE 7EH TO DIGIT 7

      MOVE    ACC, A[3]                   ; PROCESS DIGIT 2
      SUB     #9
      JUMP    Z, INCREASE_DIGIT1         ; DIGIT 2 = 9, THERE IS CARRY
OVER
      MOVE    ACC, A[3]                   ; DIGIT 2 < 9, CONTINUE
      ADD     #1
      MOVE    A[3], ACC
      CALL    FONT_LOOKUP                 ; LOOK UP THE VALUE FOR THIS
FONT
      ; STORE IT IN A[9], KEEP ACC
UNCHANGED
      OR      #6200H
      CALL    MAX6951_TRANSMIT
NEW VALUE                                ; NO CARRY OVER, WRITE DIGIT 2
      MOVE    ACC, A[9]
DIGIT 6                                  ; WRITE THE NO DECODE VALUE TO
      OR      #6600H
      CALL    MAX6951_TRANSMIT
      JUMP    DISPLAY_NUMBER

INCREASE_DIGIT1:
      OR      #6200H
      CALL    MAX6951_TRANSMIT           ; WRITE 0 TO DIGIT 2 REGISTER
FIRST
      MOVE    A[3], #0                   ; SET DIGIT 2 BACK TO 0
      MOVE    ACC, #667EH                ; NO DECODE VALUE FOR FONT '0'
IS "7EH"
REGISTER
      CALL    MAX6951_TRANSMIT           ; WRITE 7EH TO DIGIT 6

      MOVE    ACC, A[2]                   ; PROCESS DIGIT 1
      SUB     #9
      JUMP    Z, INCREASE_DIGIT0         ; DIGIT 1 = 9, THERE IS CARRY
OVER
      MOVE    ACC, A[2]                   ; DIGIT 1 < 9, CONTINUE
      ADD     #1
      MOVE    A[2], ACC
      CALL    FONT_LOOKUP                 ; LOOK UP THE VALUE FOR THIS
FONT
      ; STORE IT IN A[9], KEEP ACC
UNCHANGED
      OR      #6100H
      CALL    MAX6951_TRANSMIT
NEW VALUE                                ; NO CARRY OVER, WRITE DIGIT 1
      MOVE    ACC, A[9]
DIGIT 5                                  ; WRITE THE NO DECODE VALUE TO
      OR      #6500H

```

```

        CALL    MAX6951_TRANSMIT
        JUMP    DISPLAY_NUMBER

INCREASE_DIGIT0:
        OR     #6100H
        CALL    MAX6951_TRANSMIT           ; WRITE 0 TO DIGIT 1 REGISTER
FIRST
        MOVE   A[2], #0                   ; SET DIGIT 1 BACK TO 0
        MOVE   ACC, #657EH                ; NO DECODE VALUE FOR FONT '0'
IS "7EH"
        CALL    MAX6951_TRANSMIT           ; WIRTE 7EH TO DIGIT 5
REGISTER

        MOVE   ACC, A[1]                  ; PROCESS DIGIT 0
        SUB    #9
        JUMP   Z, COUNT_COMPLETE           ; DIGIT 0 = 9, COUNTING IS
OVER
        MOVE   ACC, A[1]                  ; DIGIT 0 < 9, CONTINUE
        ADD    #1
        MOVE   A[1], ACC
        CALL    FONT_LOOKUP                ; LOOK UP THE VALUE FOR THIS
FONT
                                                ; STORE IT IN A[9], KEEP ACC
UNCHANGED
        OR     #6000H
        CALL    MAX6951_TRANSMIT           ; NO CARRY OVER, WRITE DIGIT 0
NEW VALUE
        MOVE   ACC, A[9]                  ; WRITE THE NO DECODE VALUE TO
DIGIT 4
        OR     #6400H
        CALL    MAX6951_TRANSMIT

DISPLAY_NUMBER:           ; DISPLAY DIGIT 3-0 IN HEXADECIMAL DECODE MODE
                        ; DIEPLAY DIGIT 7-4 IN NO DECODE MODE
        CALL    MAX6951_ENABLE
        CALL    MAX6951_10MS_DELAY
        JUMP    COUNT_LOOP

COUNT_COMPLETE:
        RET

```

**maxq2000\_spi.asm file:** This file is the utility function for configuring and using the MAXQ2000's SPI module. The file is integrated in the MAX-IDE; the user can use it without modification.

**divide32.asm file:** This is a 32-/32-bit divide routine provided in the MAX-IDE software.

**maxq2000.inc, maxq2000\_spi.inc, and max2000ev\_6951.inc files:** These are include files for MAXQ2000 pin definitions and MAX6951 register definitions.

## Conclusion

The MAX6951/MAX6950 SPI LED drivers are easy-to-use common-cathode display drivers that interface to microcontrollers through an SPI serial interface. The MAXQ family of microcontrollers provides a convenient integrated SPI module that communicates to LED drivers with SPI interfaces. The sample code presented here helps a user understand how to exercise MAX6951 LED features. The sample code can also be utilized in similar MAXQ2000-based application development.

### Related Parts

[MAX6950](#)

Serially Interfaced, +2.7V to +5.5V, 5- and 8-Digit LED Display Drivers

[Free Samples](#)

<a href="#">MAX6951</a>	Serially Interfaced, +2.7V to +5.5V, 5- and 8-Digit LED Display Drivers	<a href="#">Free Samples</a>
<a href="#">MAXQ2000</a>	Low-Power LCD Microcontroller	<a href="#">Free Samples</a>

---

**More Information**

For Technical Support: <http://www.maximintegrated.com/support>

For Samples: <http://www.maximintegrated.com/samples>

Other Questions and Comments: <http://www.maximintegrated.com/contact>

---

Application Note 3729: <http://www.maximintegrated.com/an3729>

APPLICATION NOTE 3729, AN3729, AN 3729, APP3729, Appnote3729, Appnote 3729

Copyright © by Maxim Integrated Products

Additional Legal Notices: <http://www.maximintegrated.com/legal>